

# PROBLEM SOLVING GUIDE



## Organic Stains

Including, but not limited to bark, bird droppings, food, dirt, leaves and tobacco.

| OPTIONS   | STEPS   |
|---|---|
| <p><b>DEEP CLEANER</b></p>  <p><b>COVERAGE</b><br/>33 TO 100<br/>SQ. FT. PER<br/>32 oz.</p>          | <ol style="list-style-type: none"> <li>1. SWEEP OR VACUUM SURFACE TO BE CLEANED TO REMOVE ANY LOOSE CONTAMINANTS.</li> <li>2. APPLY <b>DEEP CLEANER</b> LIBERALLY WITH TRIGGER SPRAY BOTTLE ON THE SURFACE TO BE CLEANED. MAKE SURE TO FULLY WET THE SURFACE.</li> <li>3. ALLOW <b>DEEP CLEANER</b> TO DWELL ON SURFACE FOR 5 -10 MINUTES. PRODUCT SHOULD NOT DRY ON THE SURFACE.<br/><b>EXPERT TIP:</b> IF NEEDED, SIMPLY SPRAY ADDITIONAL PRODUCT ON THE SURFACE TO KEEP WET.</li> <li>4. AGITATE WITH A PRIMO TOOLS™ WHITE NYLON SCRUB PAD OR OTHER COMPARABLE NON-MARRING SCRUBBING TOOL UNTIL SURFACE IS CLEAN.</li> <li>5. THOROUGHLY RINSE SURFACE WITH WATER. A WET/DRY VACUUM MAY ALSO BE USED.</li> <li>6. SOME SURFACES MAY REQUIRE ADDITIONAL APPLICATIONS.</li> <li>7. WIPE SURFACE COMPLETELY DRY USING A CLEAN, DRY, WHITE COTTON OR MICRO-FIBER TOWEL.</li> <li>8. IF SURFACE IS TO BE SEALED, ALLOW 24 HOURS DRYING TIME PRIOR TO APPLYING A HIGH QUALITY OMNI SEALER.</li> </ol>  |
| <p><b>HEAVY DUTY CLEANER</b></p>  <p><b>COVERAGE</b><br/>200 TO 2,000<br/>SQ. FT. PER<br/>GALLON</p> | <ol style="list-style-type: none"> <li>1. SWEEP OR VACUUM SURFACE TO BE CLEANED TO REMOVE ANY LOOSE CONTAMINANTS.</li> <li>2. DILUTE <b>HEAVY DUTY CLEANER</b> WITH WATER TO MATCH CLEANING NEEDS: 1 PART TO 2 PARTS WATER – HEAVY DUTY; 1 PART TO 5 PARTS WATER – MEDIUM DUTY; 1 PART TO 40 PARTS WATER – LIGHT DUTY<br/><b>EXPERT TIP:</b> WARM WATER ENHANCES <b>HEAVY DUTY CLEANER'S</b> PERFORMANCE.</li> <li>3. LIBERALLY APPLY CLEANING SOLUTION TO THE SURFACE TO BE CLEANED WITH A SPONGAUSA™ SPONGE, OR A MOP OR BRUSH.</li> <li>4. ALLOW CLEANING SOLUTION TO DWELL ON SURFACE FOR UP TO 5 MINUTES.</li> <li>5. AGITATE WITH A PRIMO TOOLS™ WHITE NYLON SCRUB PAD OR A MOP, NATURAL-BRISTLE BRUSH OR OTHER COMPARABLE NON-MARRING SCRUBBING TOOL UNTIL SURFACE IS CLEAN.</li> <li>6. MOP UP DIRTY SOLUTION. A WET/DRY VACUUM MAY ALSO BE USED.</li> <li>7. THOROUGHLY RINSE SURFACE WITH WATER, CHANGING WATER AT LEAST EVERY 250 SQ. FT.</li> <li>8. WIPE SURFACE COMPLETELY DRY USING A CLEAN, DRY, WHITE COTTON OR MICRO-FIBER TOWEL.</li> <li>9. IF SURFACE IS TO BE SEALED, ALLOW 24 HOURS DRYING TIME PRIOR TO APPLYING A HIGH QUALITY OMNI SEALER.</li> </ol> |
| <p><b>ELITE CLEANER</b></p>  <p><b>COVERAGE</b><br/>200 TO 2,000<br/>SQ. FT. PER<br/>GALLON</p>    | <ol style="list-style-type: none"> <li>1. SHAKE WELL BEFORE EACH USE.</li> <li>2. SWEEP OR VACUUM SURFACE TO BE CLEANED TO REMOVE ANY LOOSE CONTAMINANTS.</li> <li>3. APPLY <b>ELITE CLEANER</b> LIBERALLY ON SURFACE TO BE CLEANED DIRECTLY FROM BOTTLE OR WITH A SPONGAUSA™ SPONGE, OR A BRUSH OR SCRUB MACHINE.</li> <li>4. ALLOW <b>ELITE CLEANER</b> TO DWELL ON SURFACE FOR UP TO 5 MINUTES.</li> <li>5. AGITATE WITH A PRIMO TOOLS™ WHITE NYLON SCRUB PAD, OR A BRUSH OR OTHER COMPARABLE NON-MARRING SCRUBBING TOOL UNTIL CONTAMINATE OR STAIN IS REMOVED.</li> <li>6. THOROUGHLY RINSE SURFACE WITH WATER. A WET/DRY VACUUM MAY ALSO BE USED.<br/><b>EXPERT TIP:</b> HIGH-PRESSURE (1000–3000 PSI) SPRAYERS ARE HIGHLY EFFECTIVE AT RINSING AWAY CONTAMINATES AND STAINS WHEN USED IN CONJUNCTION WITH <b>ELITE CLEANER</b>.</li> <li>7. WIPE SURFACE COMPLETELY DRY USING A CLEAN, DRY, WHITE COTTON OR MICRO-FIBER TOWEL.</li> <li>8. IF SURFACE IS TO BE SEALED, ALLOW 24 HOURS DRYING TIME PRIOR TO APPLYING A HIGH QUALITY OMNI SEALER.</li> </ol>  |

Technical Support: 949-709-5270 Mon thru Fri 6:00am PT to 4:00pm PT and/or E-mail [TechSupport@OMNI-Sealers.com](mailto:TechSupport@OMNI-Sealers.com).

Problem Solving Guide is a general recommendation. Actual results may vary. Read product directions thoroughly before use.  
**ALWAYS TEST IN A SMALL INCONSPICUOUS AREA.**