

PROBLEM SOLVING GUIDE

Organic Stains

Including, but not limited to bark, bird droppings, food, dirt, leaves and tobacco.



OPTIONS

**POULTICE STAIN
REMOVER**



COVERAGE
25 TO 75
SQ. FT. PER
12 OZ.

STEPS

DEEP SET STAINS

1. SWEEP OR VACUUM SURFACE TO BE CLEANED TO REMOVE ANY LOOSE CONTAMINANTS.
2. MIX **POULTICE STAIN REMOVER** WITH WATER TO FORM A THICK PASTE.
EXPERT TIP: CAN USE **DEEP CLEANER** OR **HEAVY DUTY CLEANER** IN PLACE OF WATER FOR ENHANCED PERFORMANCE.
3. APPLY **POULTICE STAIN REMOVER** PASTE APPROXIMATELY $\frac{1}{4}$ " THICK TO STAINED SURFACE. ALLOW PASTE TO EXTEND BEYOND THE EDGES OF THE STAIN BY AT LEAST 1".
4. COVER PASTE WITH PLASTIC AND TAPE EDGES OF PLASTIC TO SURFACE WITH PAINTER'S-TYPE TAPE.
5. ALLOW PASTE TO DWELL ON SURFACE UNDER PLASTIC FOR 24 TO 48 HOURS.
6. REMOVE THE PLASTIC COVERING THE PASTE.
7. REMOVE PASTE WITH A NON-MARRING TOOL (PLASTIC PUTTY KNIFE).
8. AFTER STAIN HAS BEEN REMOVED, CLEAN PASTE WITH A SPONGAUSA™ SPONGE, OR A WHITE, COTTON OR MICRO-FIBER TOWEL AND WATER.
9. THOROUGHLY RINSE SURFACE WITH WATER & DRY WITH A WHITE COTTON OR MICRO-FIBER TOWEL. A WET/DRY VACUUM MAY ALSO BE USED.
10. SOME SURFACES MAY REQUIRE ADDITIONAL APPLICATIONS.
11. IF SURFACE IS TO BE SEALED, ALLOW 24 HOURS DRYING TIME PRIOR TO APPLYING A HIGH QUALITY OMNI SEALER.

SURFACE STAINS

1. SWEEP OR VACUUM SURFACE TO BE CLEANED TO REMOVE ANY LOOSE CONTAMINANTS.
2. APPLY A SMALL AMOUNT OF WATER TO SURFACE TO BE CLEANED.
3. LIBERALLY SPRINKLE **POULTICE STAIN REMOVER** TO THE WET SURFACE AND MIX INTO THIN SLURRY.
EXPERT TIP: FOR STAINS ON VERTICAL SURFACES, MIX POULTICE STAIN REMOVER WITH WATER INTO SLURRY IN A CONTAINER, THEN APPLIED TO THE WET SURFACE.
4. SCRUB SURFACE WITH A PRIMO TOOLS™ WHITE NYLON SCRUB PAD OR OTHER COMPARABLE NON-MARRING SCRUBBING TOOL UNTIL STAIN IS REMOVED FROM SURFACE.
EXPERT TIP: FOR LARGE STAIN SURFACES, A LOW RPM (300-750 RPM) BUFFER CAN BE USED WITH A WHITE NYLON PAD TO REMOVE STAINS. KEEP SURFACE WET DURING BUFFING PROCESS.
5. AFTER STAIN HAS BEEN REMOVED, CLEAN WITH A SPONGAUSA™ SPONGE, OR A WHITE, COTTON OR MICRO-FIBER TOWEL AND WATER.
6. THOROUGHLY RINSE SURFACE WITH WATER & DRY WITH A WHITE COTTON OR MICRO-FIBER TOWEL. A WET/DRY VACUUM MAY ALSO BE USED.
7. SOME SURFACES MAY REQUIRE ADDITIONAL APPLICATIONS.
8. IF SURFACE IS TO BE SEALED, ALLOW 24 HOURS DRYING TIME PRIOR TO APPLYING A HIGH QUALITY OMNI SEALER

Technical Support: 949-709-5270 Mon thru Fri 6:00am PT to 4:00pm PT and/or E-mail TechSupport@OMNI-Sealers.com.

Problem Solving Guide is a general recommendation. Actual results may vary. Read product directions thoroughly before use.
ALWAYS TEST IN A SMALL INCONSPICUOUS AREA.