

PROBLEM SOLVING GUIDE

Grout: Dirty, Stained, Faded or Inconsistent Color



OPTIONS	STEPS
<p>GROUT RECOLORING SEALER</p>  <p>COVERAGE 50 TO 300 SQ. FT. PER 8 OZ.</p>	<ol style="list-style-type: none">1. SHAKE WELL BEFORE EACH USE.2. UNSCREW WHEEL-APPLICATOR TOP, REMOVE INNER RED SEAL FROM THE NECK OF THE BOTTLE AND RE-ATTACH TOP.3. HOLD BOTTLE IN A NEAR VERTICAL POSITION, SQUEEZE GENTLY AND CONTINUOUSLY ROLL GROUT RE-COLORING SEALER ALONG THE GROUT JOINT UNTIL THE SEALER APPEARS.4. FOR HARD TO REACH PLACES SUCH AS AROUND FIXTURES, CORNERS OR WIDE GROUT JOINTS, USE THE BRUSH-APPLICATOR.5. LIMIT THE AMOUNT OF PRODUCT THAT GETS ON THE SURFACE.6. BEFORE GROUT RE-COLORING SEALER IS COMPLETELY DRY (BETWEEN 1 AND 8 HOURS), LIGHTLY WET SURFACE WITH WATER USING A SLIGHTLY DAMPENED SPONGAUSA™ SPONGE (INCLUDED). A LIGHT SPRAY MIST OF WATER CAN ALSO BE USED.7. REMOVE EXCESS GROUT RE-COLORING SEALER FROM SURFACE USING THE YELLOW SIDE OF THE SCRUBBER SPONGE. AVOID SCRUBBING DIRECTLY ON THE GROUT JOINT. EXPERT TIP: IF GROUT RECOLORING SEALER IS DIFFICULT TO REMOVE, USE THE WHITE SIDE OF THE SCRUBBER SPONGE.10. SOME GROUT JOINTS MAY REQUIRE 2 OR MORE COATS, ESPECIALLY IF CHANGING FROM A DARK TO LIGHT GROUT COLOR OR WHEN GROUT IS BADLY DISCOLORED.11. ALLOW AT LEAST 2 HOURS DRYING TIME BETWEEN COATS.12. SURFACE IS READY FOR TRAFFIC IN 12 HOURS. KEEP AREA DRY FOR AT LEAST 24 HOURS.
<p>BUFFERED ACID CLEANER</p>  <p>COVERAGE 500 TO 2,000 SQ. FT. PER GALLON</p>	<ol style="list-style-type: none">1. SWEEP OR VACUUM SURFACE TO BE CLEANED TO REMOVE ANY LOOSE CONTAMINANTS.2. USE FULL STRENGTH OR DILUTE WITH WATER TO MATCH CLEANING NEEDS: FULL STRENGTH – EXTREME DUTY; 1 PART TO 2 PARTS WATER – HEAVY DUTY; 1 PART TO 5 PARTS WATER – MEDIUM DUTY; 1 PART TO 15 PARTS WATER – LIGHT DUTY3. APPLY A LIBERAL AMOUNT OF WATER TO THE SURFACE TO BE CLEANED.4. APPLY BUFFERED ACID CLEANER USING A SPONGAUSA™ SPONGE, OR A MOP OR BRUSH. EXPERT TIP: FOR LARGE PROJECTS, DIVIDE WORKING AREA INTO MANAGEABLE SECTIONS OF APPROX. 25 SQ. FT.5. ALLOW BUFFERED ACID CLEANER TO DWELL ON SURFACE FOR 1 TO 5 MINUTES ON SURFACE.6. AGITATE WITH A PRIMO TOOLS™ WHITE NYLON SCRUB PAD, OR BRUSH OR OTHER COMPARABLE NON-MARRING SCRUBBING TOOL UNTIL CONTAMINATE OR STAIN IS REMOVED FROM SURFACE.7. THOROUGHLY RINSE SURFACE WITH WATER. A WET/DRY VACUUM MAY ALSO BE USED.8. SOME SURFACES MAY REQUIRE ADDITIONAL APPLICATIONS. EXPERT TIP: HIGH-PRESSURE (1000 – 3000 PSI) SPRAYERS ARE HIGHLY EFFECTIVE AT RINSING AWAY CONTAMINANTS AND STAINS WHEN USED IN CONJUNCTION WITH BUFFERED ACID CLEANER.9. WIPE SURFACE COMPLETELY DRY USING A CLEAN, DRY, WHITE COTTON OR MICRO-FIBER TOWEL.10. IF SURFACE IS TO BE SEALED, ALLOW 24 HOURS DRYING TIME PRIOR TO APPLYING A HIGH QUALITY OMNI SEALER. EXPERT TIP: BUFFERED ACID CLEANER MAY ETCH, LIGHTEN OR ALTER THE COLOR OF ACID SENSITIVE SURFACES.
<p>SULFAMIC ACID CLEANER</p>  <p>COVERAGE 3000 TO 16,000 SQ. FT. PER 4# JAR</p>	<ol style="list-style-type: none">1. SWEEP OR VACUUM SURFACE TO BE CLEANED TO REMOVE ANY LOOSE CONTAMINANTS.2. DISSOLVE SULFAMIC ACID CLEANER IN WATER TO MATCH CLEANING NEEDS: ¾ CUP TO 1 GALLON WATER – HEAVY DUTY; ½ CUP TO 1 GALLON WATER – MEDIUM DUTY; ¼ CUP TO 1 GALLON WATER – LIGHT DUTY3. APPLY A LIBERAL AMOUNT OF WATER TO THE SURFACE TO BE CLEANED.4. APPLY SULFAMIC ACID CLEANER USING A SPONGAUSA™ SPONGE, OR A MOP OR BRUSH. EXPERT TIP: FOR LARGE PROJECTS, DIVIDE WORKING AREA INTO MANAGEABLE SECTIONS OF APPROX. 25 SQ. FT.5. ALLOW SULFAMIC ACID CLEANER TO DWELL ON SURFACE FOR 1 TO 5 MINUTES.6. AGITATE WITH A PRIMO TOOLS™ WHITE NYLON SCRUB PAD, OR A BRUSH OR OTHER COMPARABLE NON-MARRING SCRUBBING TOOL UNTIL CONTAMINATE OR STAIN IS REMOVED FROM SURFACE.7. THOROUGHLY RINSE SURFACE WITH WATER. A WET/DRY VACUUM MAY ALSO BE USED.8. SOME SURFACES MAY REQUIRE ADDITIONAL APPLICATIONS. EXPERT TIP: HIGH-PRESSURE (1000 – 3000 PSI) SPRAYERS ARE HIGHLY EFFECTIVE AT RINSING AWAY CONTAMINATES AND STAINS WHEN USED IN CONJUNCTION WITH SULFAMIC ACID CLEANER.9. WIPE SURFACE COMPLETELY DRY USING A CLEAN, DRY, WHITE COTTON OR MICRO-FIBER TOWEL.10. IF SURFACE IS TO BE SEALED, ALLOW SURFACE TO DRY 24 HOURS PRIOR TO APPLYING A HIGH QUALITY OMNI SEALER.

Technical Support: 949-709-5270 Mon thru Fri 6:00am PT to 4:00pm PT and/or E-mail TechSupport@OMNI-Sealers.com

Problem Solving Guide is a general recommendation. Actual results may vary. Read product directions thoroughly before use.

ALWAYS TEST IN A SMALL INCONSPICUOUS AREA.